


Accelerometers: investigating animal´s activity

Anne Berger
berger@izw-berlin.de



— What do we know about the collared animals?

- Characteristics of the animals
species, sex, age class, ...
- Positions of the animals
at special times -> movement models
- Environmental information
habitat type, NDVI (Normalized Density Vegetation Index), temperature,
remote sensing data...

But you still don't know what the animal is **doing there !**

Behaviour = fast and direct reaction to environmental changes
= direct interaction to other animals (conspecifics & other species)
= indicator of animal wellbeing or stress


Do you really want renounce such important information ?!

How to measure wildlife behaviour without affecting it?




How an accelerometer works

- a spring-like piezo-electronic sensor that measures the rate of change of velocity with respect to time (acceleration)
- sensor is deformed by inertial acceleration (due to movement of the device)



How an accelerometer works


- a spring-like piezo-electronic sensor that measures the rate of change of velocity with respect to time (acceleration)
- sensor is deformed by inertial acceleration (due to movement of the device) **AND by gravitational acceleration (g)**



$$1 \text{ g} = 9.81 \text{ ms}^{-1}$$


— Different types of acceleration measurement

- can be user-programmed to sample frequencies **from 0.5 to 10,000 Hz**
- can be set to record **continuously or in repeated bursts** (e.g., every 2 min)
- can weigh 0.7 g (without a battery) and measure $9.5 \times 15 \times 4$ mm
- consume very little digital memory with each measurement, so data collection and data storage on-board is possible **for up to** several months or years, **depending on the sampling schedule**
- **possibility** to download the data from a reasonable distance (up to 500 m or by airplane)




Different types of acceleration measurement

Ethosys, Esys





Vectronic, Lotek




E-obs, WAS, Vectronic






Different types of acceleration measurement



- Scheibe et al. (1998) Appl Anim Behav Sci 55
- www.esys.de ALT-Pedometer
- **sensor:** one in all dimension
- plus head position sensor (up or down)
- **measure:** existence of vibrations within a second given as zero or one
- **storage interval:** 1-60 min
- **data:** total numbers of measures per storage interval
- no data gaps
- **output:** ASCII-files



Different types of acceleration measurement





- Scheibe et al. (1998) Appl Anim Behav Sci 55
- www.esys.de ALT-Pedometer
- column 1: date & start time of measuring interval
- column 2 & 3: measured behaviour
[number of seconds per measuring interval]
- storage capacity: about 4,000 data sets
- battery capacity: 3 years (sheep, horse)
- transmission per radio
- without GPS-tool

Original data


date/time	activity	activity head down
05.02.05 08:40	784	56
05.02.05 08:55	36	0
05.02.05 09:10	664	0
05.02.05 09:25	734	1
05.02.05 09:40	138	44
05.02.05 09:55	43	0
05.02.05 10:10	199	23
05.02.05 10:25	868	0
05.02.05 10:40	753	0
05.02.05 10:55	796	28
05.02.05 11:10	900	12
05.02.05 11:25	820	460
05.02.05 11:40	618	0
05.02.05 11:55	762	0
05.02.05 12:10	73	19
05.02.05 12:25	62	32
05.02.05 12:40	609	52
05.02.05 12:55	863	0
05.02.05 13:10	508	4
05.02.05 13:25	80	11

Different types of acceleration measurement



general activity
grazing


number of seconds
per measuring interval




Time (storage interval: 15 min)

Different types of acceleration measurement


Ethosys, Esys





Vectronic, Lotek



E-obs, WAS, Vectronic




— Different types of acceleration measurement





www.vectronic-aerospace.com
www.lotek.com

- two uni-directional sensors (x and y)
- angular adjustment tool
- **measure:** difference in acceleration between two consecutive measurements (6-8 per sec)
- **storage interval:** minimum: 64 sec and up (with steps of 8 seconds)



— Different types of acceleration measurement



www.vectronic-aerospace.com
www.lotek.com


- **data:** means (given within a relative range of 0-255) per storage interval (2-5 min)
- **output:** company specific files (*.ADF)
- older versions: data gaps during GPS-positioning

Original data


DATE	TIME	ACTIVITY_X	ACTIVITY_Y	TEMP
29.07.03	11:00:00	3	2	30
29.07.03	11:05:00	0	0	30
29.07.03	11:10:00	0	0	30
29.07.03	11:15:00	0	0	29
29.07.03	11:20:00	0	0	29
29.07.03	11:30:00	0	1	29
29.07.03	11:35:00	0	0	30
29.07.03	11:40:00	0	0	30
29.07.03	11:45:00	0	0	31
29.07.03	11:50:00	0	0	31
29.07.03	11:55:00	0	0	31
29.07.03	12:00:00	0	0	32
29.07.03	12:05:00	0	0	32
29.07.03	12:10:00	3	2	32
29.07.03	12:15:00	18	7	32
29.07.03	12:20:00	0	0	32
29.07.03	12:25:00	0	0	33
29.07.03	12:30:00	0	0	33
29.07.03	12:40:00	0	0	33
29.07.03	12:45:00	7	3	33
29.07.03	12:50:00	25	10	31
29.07.03	12:55:00	11	4	30
29.07.03	13:00:00	5	2	31
29.07.03	13:05:00	0	0	31
29.07.03	13:10:00	0	0	31
29.07.03	13:15:00	0	0	31
29.07.03	13:20:00	4	1	32
29.07.03	13:25:00	0	0	30
29.07.03	13:30:00	0	0	29

Different types of acceleration measurement


Ethosys, Esys



Vectronic, Lotek




E-obs, WAS, Vectronic




Different types of acceleration measurement


Ethosys, Esys






Vectronic, Lotek



E-obs, WAS, Vectronic



— Different types of acceleration measurement




Scheibe & Gromann (2006) BRMIC




www.e-obs.de

www.esysautomation.com

- 3 uni-directional sensors (x, y and z)
- **measure:** linear accelerations in the three axes of space within a time interval (10-1,000 msec)
- **data:** absolute values within the record interval (10-1,000 msec)
- no threshold tool



— Different types of acceleration measurement




You want to know the behaviour of every 5 minutes

You have to be able to identify the single behaviour within the record time

Attention: minimal duration of behaviour you want to measure should be longer than the time between the records

User defined record time = "burst" (e.g., 10 seconds)

time between the records (e.g., 4 min & 50 sec) without measurements !





Leibniz Institute for Zoo
and Wildlife Research
an der Humboldt-Universität Berlin



— What can we do with these data ?

Brown et al. *Animal Biotelemetry* 2013, 1:20
<http://www.animalbiotelemetry.com/content/1/1/20>




REVIEW

Open Access

Observing the unwatchable through acceleration logging of animal behavior

Danielle D Brown^{1*}, Roland Kays^{2,3,4}, Martin Wikelski^{4,5,6}, Rory Wilson⁷ and A Peter Klimley⁸

3D-path reconstruction (under water)




Calculation of:

- The rotation angles around the lateral and longitudinal axes and estimate the gravity-based acceleration (3D-vector calculation)

Output:

- Reconstruction of path or dive positions and their connection to environment

Calculation of energy expenditure



Calculation of:


- Accelerometry (allows quantification of the movement) by overall or partial dynamic body acceleration (ODBA/PDBA) and calibration within different conditions (mostly in lab)

Output:

- Metabolic rates

Daily and annual activity pattern analysis

Male moose (*Alces alces*), Scandinavia



Calculation of:

- means / medians
- day-night relation = diurnality index
- number, length and duration of daily activity or resting phases

Output:

- general activity pattern
- activity relation to dawn & dusk
- adaptation to seasons and habitats
- influence or timing of certain events (e.g., reproduction, migration, hunt, calving, denning...)

Software:

- Activity Pattern (Vectronic)
- Python or R-package


Berger et al. (1999) Appl. Anim. Behav. Sci. 64 -> Przewalski horses

Berger et al. (2002) Biol. Rhythm Res. 33 -> red deer

Krop-Benesch et al. (2013) Italian Journal of Zoology -> roe deer

Detection & evaluation of disturbances / stress

Illness on mouffon (*Ovis orientalis*)




Calculation of:

- daily mean (mean)
- diurnality index (DI)
- autocorrelation
- power spectrum
- Degrees of Functional Coupling (DFC)
- Harmonic Parts (HP)

Output:

- coupling between the internal circadian rhythm and external environmental periodicities
- detection of disturbances and stressing conditions in wildlife on a daily level

Detection of different behaviours (1-2D)



Calculation of:

- plot the frequency distribution of activity classes
- define the separation point = activity class with the lowest frequency between the 2 modes (need: bimodal pattern)

Output:

- individual threshold to discriminate active and passive behaviour

Detection of different behaviours (1-2D)




Figure 2. Threshold values (thick vertical lines) to separate resting (R) from feeding/slow locomotion (F/sLoc) and the latter from fast locomotion (fLoc) for x-values, y-values and the sums of x- and y-values as determined by recursive partitioning, and overlapping zones (grey bars) after 5,000 bootstraps. White bars denote 95% confidence intervals after 5,000 bootstraps. Thresholds are built from pooled data of four individuals (compare with Table 1).





Calculation of:

- comparison of observed behavioural categories and acceleration values at the same time
- ANOVA

Output:

- determination of thresholds to differ activity states

Detection of different behaviours (3D)



Calculation of:

- periodogram
- frequency distribution
- fractal dimension
- ODBA (overall dynamic body acceleration)
- moving window of pattern analysis


Output:

- differentiation of several behaviours (fine scale)
- only possible for behavior of characteristic pattern in space and time


Detection of different behaviours (3D)




Resting





Trotting




Foraging




Walking




Stocking



Drinking



Grooming



Detection of different behaviours (3D)

used (supervised) machine learning methods

Linear Discriminant Analysis (LDA)

LDA is a dimensionality reduction algorithm in order to find a linear combination of features (predictors) that characterizes or separates the different classes (behaviours). LDA is for homogeneous variance-covariance matrices.

Quadratic Discriminant Analysis (QDA)

QDA is similar to LDA but is used for heterogeneous variance-covariance matrices. Quadratic discriminant analysis calculates a Quadratic Score Function.

K-Nearest Neighbor (KNN)

An object is classified by a majority vote of its neighbors, with the object being assigned to the class most common among its k nearest neighbors (k is a positive integer, typically small). If $k = 1$, then the object is simply assigned to the class of that single nearest neighbor.

Classification and Regression Tree (CART)


Decision tree methods construct a model of decisions made based on actual values of attributes in the data. Decisions fork in tree structures (nodes and leaves) until a prediction decision is made for a given record.

There are a lot more! (Artificial Neural Network Algorithms, support vector machine, random forest)

Development of functional habitat maps

Daily routine of a roe deer (calculated by ODBA)


tag: 1569 01.03.2012



Development of functional habitat maps


Classification of active & passive phases

tag: 1569 01.03.2012




Development of functional habitat maps

Join behaviour and GPS-positions




Development of functional habitat maps




Which measurement suits to which analysis ?


Ethosys, Esys



Vectronic, Lotek



E-obs, WAS, Vectronic



Annual
basic
pattern



Stress
detection



In general
possible
but not
done yet

To differ
behaviours



Only general
activity &
grazing



Only resting
and very fast
locomotion



Functional
habitat
maps




Only general
activity/
grazing & VHF






Only resting
and very fast
locomotion



Outlook




- 3D-accelerometers & other sensors (light, temperature, sound, humidity...)
- continuous measurements
- on-board behaviour classification by unsupervised pattern detection algorithms
- real-time data viewing via web



future

Outlook



Take home messages

- Be clear about your study question !
- AFTER, choose your measuring/analyzing methods according to your study question !
(do literature search and communicate with the community because the market is growing rapidly)
- IF you need to measure special behaviours, behaviour disturbances, energy consumptions, or functional habitat maps to answer your study question, the use of accelerometers is highly recommended !
- If you are rather a spatial data analyst, ask specialists in activity data analysis (maybe me :-)) -> These analyses are learnable!